


### ROUNDTEST RA-120/RA-120P

**COMPACT ROUNDNESS MEASUREMENT** 






### Roundtest RA-120



### Simple, interactive display screen

The large LCD screen with backlight shows easy-to-understand measurement results and graphs. Forms can be checked and notch processing can be set while observing the displayed graphs.





This compact roundness measuring machine is provided with numerous user-friendly features aimed at prioritising usability, such as a wider range for the detector, an easy-to-understand operation panel with large LCD, a D.A.T. function that powerfully supports centering and leveling adjustments, and so on.

### Operating panel that is read at a glance

### **Supports 16 languages**

Japanese, English, German, French, Italian, Spanish, Portuguese, Korean, Traditional Chinese, Simplified Chinese, Czech, Polish, Hungarian Turkish, Swedish, Dutch

#### Analysis type

Selection buttons provide access to a wide variety of analysis types

### Switching screen modes

Switch the display at the touch of a button, providing access to the Calibration, Centering and Leveling, Measurement, and Result screens

### Zero-setting button

No fine adjustment necessary for setting the measurement position



### Simple setup

Apply the current measurement setup in one go Simple operation helps prevent operational errors

### Jog dial


Make detailed changes to setup and other operations

### **USB Communication Program for ROUNDTEST RA-120**

The Roundtest RA-120 has a USB interface, enabling data to be transferred to a spreadsheet or other software

### Notch processing


Unwanted data, such as that produced by notches or scratches, can be excluded from the analysis if desired. Select between Automatic setting and Arbitrary setting.



### High-grade thermal printer

Print measurement conditions, computation results, result graphs, comments, etc., to the thermal printer. Change development graphs and output items as desired.

Sample prints



Recording paper set (optional set of 10 rolls)

### File save

Save and access Measurement files and Result files in USB memory. Data can also be totaled using the data output function with commercial tabulation software.




### Roundtest RA-120P



### ROUNDPAK software – powerful and easy to use


By using a mouse and buttons, identified by corresponding icons, to control the machine, the software ROUNDPAK interface provides excellent usability. Functions such as recalculation and graph reading are handled swiftly with easy-to-understand operations.






This entry-level desktop tester incorporates the ROUNDPAK multi-analysis evaluation program, which provides it with analytical power close to that of more elaborate models. This is, therefore, a highly functional multi-analysis roundness measuring machine that is suitable for use not only in measurement rooms, but also in research and development sections.


### Measurement screen make sample use of graphs



### **Multi-analysis function**


Complete with a wide range of functions including partial enlargement, auxiliary line setup, colour change, displacement/angular difference of data between two points, and so on. Also equipped with notch processing and graph reading functions, which make the machine useful in research departments. Recalculation can also be performed with the filter and evaluation method changed.







### **Simplified layout function**

Computation results for multiple items can be laid out in multiple forms on a single sheet and printed. This function also supports output to a colour printer (optional).



Layout setting screen





Sample print outputs



# Functions that implement greater efficiency of measurement and range of analysis types


### D.A.T. function (except for centering/leveling device with analog micrometer heads)

This instrument uses the D.A.T. (Digital Adjustment Table) function available on more sophisticated models, and this provides powerful support for centering and leveling operations. To perform such operations, the user only needs to adjust the digital micrometer heads attached to the rotary table by the amounts indicated by the display. This function also supports measurement of notched workpieces.







**RA-120** 










**RA-120P** 


















Preliminary measurement





Simple adjustment



Centering/leveling complete

### **Continuous ID and OD measuring function**

This function comes in very handy when outside diameter and inside diameter surfaces need to be measured repeatedly, for example, with respect to coaxiality, deviation in wall thickness, etc. The inner surface can be measured and evaluated with the detector, maintaining the same measuring position for the outside diameter without changing its orientation, as illustrated on the right.

Inside diameters down to 50 mm can be measured.



Continuous inside and outside diameter function (inside dia. surface)



Continuous inside and outside diameter function (outside dia. surface)

### **Z-axis scale**


This scale is useful when the measuring height position needs to be entered, such as when measuring coaxiality, etc. The machine uses an ABS DIGIMATIC scale unit to provide an effective means for repetitive measurement and position setting.





### IN/OUT switchable wide-range detector

The range of this detector has been extended from that of a conventional lever head by as much as four times, and is now wider than ever before. The detector can provide sufficient margin for centering and leveling jobs, or when measuring large differences. Moreover, the measuring direction can be switched between inside and outside diameters with a single touch of a button.



### **Types of Analysis**


Type of analysis		Measurement mode	Evaluation diagram	RA- 120	RA- 120P
Roundness				0	О
Flatness		ψ. <del>/</del>		0	О
Perpendicularity	Relative to Axis		Against Axis	0	О
Perpend	Relative to Plane Relative to Axis	U D 1 - N	Squareness Datum plane	0	О
1	Concentricity		2xC	0	О
Coaxality Of section			1 2xC	0	О
Coax	Of axis	Axis 2 N N N N N N N N N N N N N N N N N N		_	О

Type of Analysis		Measurement mode	Evaluation diagram	RA- 120	RA- 120P
Parallelism				0	О
ariation Radial		<u> </u>	11 12-11	0	О
Thickness variation Axial Radi			12-11	0	О
Circular run-out	Radial		<u> </u>	0	О
Circular	Axial	No. of the control		0	О
Power spectrum				_	О
Profile operation			= (++)	_	О



### **Optional Accessories**

Interchangeable Styli Unit: mm



Customised special interchangeable styli are available on request. Please contact any Mitutoyo office for more information.

#### Centering chuck (knurled ring operated)

Provides good operability when measuring a small-diameter workpiece. The knurled ring allows the workpiece to be clamped easily.



Order No.	211-032
Holding range	OD with internal jaws 1–36 mm ID with internal jaws 16–69 mm OD with internal jaws 25–79 mm
External size (DxH)	ø118 x 41 mm
Mass	1.2 kg

#### Collet chuck

Provides high clamping repeatability due to the use of optional precision collets. (See table at right.)



Order No.	211-051
Part holding	ø0.5–10 mm* <sup>2</sup>
range	
Centering error	Within 50 µm*3
Mass	1.4 ka

<sup>\*2:</sup> Collets to match the workpiece size range are required for use with

### X-axis stop

Allows the user to return the detector rapidly and easily to a fixed position in the X-axis.



Order No.	12AAH320
Mass	65 g

### Three-jaw chuck (key operated)

Useful where it is necessary to apply a higher clamping force to the workpiece than can be applied with the centering chuck.



Order No.	211-014
Holding range	OD with internal jaws 2–26 mm ID with internal jaws 25–68 mm OD with internal jaws 35–78 mm
External size (D x H)	ø157 x 70.6 mm
Mass	3.8 kg

#### Individual collets\*4

These collets are for use with the collet chuck shown at left and are acquired to match the workpiece diameter range required.

•	• '
Order No.	Part Holding Range
12AAH402	ø0.5–1.0 mm
12AAH403	ø1.0–1.5 mm
12AAH404	ø1.5–2.0 mm
12AAH405	ø2.0–2.5 mm
12AAH406	ø2.5–3.0 mm
12AAH407	ø3.0–3.5 mm
12AAH408	ø3.5–4.0 mm
12AAH409	ø4.0–5.0 mm
12AAH410	ø5.0–6.0 mm
12AAH411	ø6.0–7.0 mm
12AAH412	ø7.0–8.0 mm
12AAH413	ø8.0–9.0 mm
12AAH414	ø9.0–10.0 mm

<sup>\*4:</sup> A collet cannot be mounted on the rotary table without a collet chuck.
\*4: YCC10-\*\* Class AA, made by Yukiwa Seiko Inc. or its equivalent.



Order No.	211-013
Vibration damping system	Diaphragm type air spring
External size	615 x 515 x 51 mm
Max. loading mass	150 kg

#### Microchuck

For clamping a small workpiece, 1 mm or less in diameter, that cannot be held in the centering chuck.



Order No.	211-031
Holding range	OD: up to 1.5 mm
External size (D x H)	ø118 x 48.5 mm
Mass	0.6 kg

### Auxiliary stage for a short workpiece

Order No. **356038** 



Reference hemisphere

Order No. 211-016



### Magnification checking gage

Order No. 211-045



### Gage block set for calibration

Order No. 997090



### Replacement elements for the air filter


Order No. 358592 (for filter) **358593** (filter regulator)

### **USB Communication Program for ROUNDTEST RA-120**

The Roundtest RA-120 has a USB interface, enabling data to be transferred to a spreadsheet or other software. We also provide a program that lets you create inspection record tables using a macro in Microsoft® Excel®.







#### Required environment:

 OS: Windows® XP-SP3 Windows® Vista Windows® 7 (32/64bit) Windows® 10

• Spreadsheet software: Microsoft®Excel® 2010/2016

The optional USB cable is also required.

• USB cable for RA-120 series Order No. 12AAH490

USB Communication Program as a free download on www.mitutoyo.eu!

this chuck.
\*3: When measured with ø5 mm pin gauge at measuring height of 30 mm.




### **Specifications**

### Main unit


Mall		RA-120			RA-120P			
Model		Dedicated electronic analysis type			Data analysis by PC			
	Rotational Radial	(0.04+0.0006H) µm H: Probing height (mm) JISB7451-1997						
	accuracy Axial	(0.04+0.0006X) µm X: Probing radius (mm)						
	Rotational speed	6rpm						
	Effective table diameter	150 mm						
	Centering range adjustment							
Turntable	Leveling range adjustment	±1°						
	Centering/leveling device (micrometer head)	Analog head	Digital head (mm)	Digital head (inch/mm)	Analog head	Digital head (mm)	Digital head (inch/ mm)	
	Maximum probing diameter	280 mm (380 mm in a reverse and vertical detector position)						
	Maximum workpiece diameter			44	0 mm			
	Maximum turntable loading			2	5 kg			
	Vertical travel			280 mm from	the turntable top			
Vertical column (Z-axis)	Maximum probing height	280 г	mm from the turnta	ble top (480 mm in	the reverse and vert	ical detector config	juration)	
	Maximum probing depth			100 mm (mini	mum ID: 30 mm)			
Horizontal arm (X-axis)	Horizontal travel		165 mm (Includin	g a protrusion of 25	mm from the turnta	able rotation center	·)	
	Measuring direction			Two directional (	IN/OUT switchable)			
Detector	Measuring range	±1000 µm						
Detector	Measuring force	70 to 100mN (±30%)						
	Standard stylus (12AAL021)			Carbide ball,	ø <b>1.6 mm</b> (.06")			
	Measuring range	8 steps: ±(1.000, 500, 200, 100, 50, 20, 10, 5) μm						
	Magnification	X5 to X200.000			X1 to X500.000			
	Filter type	Phase corrected: Gaussian, 2CRPC75, 2CRPC50 Not phase corrected.				ted: 2CR75, 2CR50 Filter OFF		
	Cutoff value	15upr, 50upr, 150upr, 500upr 15-150upr, 15-500upr, 50-500upr			15upr, 50upr, 150upr, 500upr, Manual 15-150upr, 15-500upr, 50-500upr, Manual			
	Number of measuring sections	Maximum 5			Maximum 100			
	Evaluation type	Roundness, Coaxality, Concentricity, Flatness, Circular run-out (radial/axial), Perpendicularity (relative to axis/plane), Thickness deviation, Parallelism						
Floring	Reference circle for evaluation	LSCI, MZCI, MICI, MCCI						
Electronic unit	Functions		rement, re-calculation ontinous ID and OD		r Notched measurement, re-calculation, limaçon error correction, remarkable point analysis (gear), harmonic analysis, continous ID and OD measurement			
	Printer		Thermal line printer		Ink-jet pri	nter compatible wit	th Windows®	
	Display languages	Japanese, English, German, French, Italian, Spanish, Portuguese, Korean, Traditional Chinese, Simplified Chinese, Czech, Polish, Hungarian, Turkish, Swedish, Dutch Czech, Polish, Hungarian, Turkish, Swedish			se, Simplified Chinese,			
	USB stick memory		Calculation result, measurement data					
	Data output RS-232C	Calculation result			lt, measurement data			
	SPC	Calcula			ation result			
	Power supply	AC 10			00 – 240V			
	Power consumption		32 – 36W			21 – 24W (excluding PC system)		
Others	Air pressure	0.39MPa						
	Air consumption	30L/min (minimum)						
	Mass	Main unit: 32 kg Air filter: 2 kg						




### **Dimensions**



### Turntable top view



### Installation floor plan





Whatever your challenges are,
Mitutoyo supports you from start to finish.

Mitutoyo is not only a manufacturer of top quality measuring products but one that also offers qualified support for the lifetime of the equipment, backed up by comprehensive services that ensure your staff can make the very best use of the investment.

Apart from the basics of calibration and repair, Mitutoyo offers product and metrology training, as well as IT support for the sophisticated software used in modern measuring technology. We can also design, build, test and deliver bespoke measuring solutions and even, if deemed cost-effective, take your critical measurement challenges in-house on a sub-contract basis.



## Find additional product literature and our product catalogue

www.mitutoyo.eu

**Note:** Product illustrations are without obligation. Product descriptions, in particular any and all technical specifications, are only binding when explicitly agreed upon. MITUTOYO and DIGIMATIC are either registered trademarks or trademarks of Mitutoyo Corp. in Japan and/or other countries/regions. YUKIWA is a registered trademark of YUKIWA SEIKO INC. Excel, Microsoft, and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Other product, company and brand names mentioned herein are for identification purposes only and may be the trademarks of their respective holders.



### Mitutoyo Europe GmbH

Borsigstraße 8-10 41469 Neuss

Tel. +49 (0) 2137-102-0 Fax +49 (0) 2137-102-351

info@mitutoyo.eu www.mitutoyo.eu